ADCRAFT®

WP-2
Warmer Plate

This manual contains important information regarding your *Admiral Craft* unit. Please read this manual thoroughly prior to equipment set-up, operation and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty. MUST READ!!!

WARNINGS

1. Do not touch any hot surfaces
2. Do not heat cold liquids. The unit is designed to keep warm liquids hot.
3. Do not immerse unit, cord or plug in liquid at any time
4. Unplug cord from outlet when not in use and before cleaning
5. Plug only into a 3-hole grounded electrical outlet
6. Do not operate unattended
7. Do not use this unit for anything other than intended use
8. Do not use outdoors
9. Keep children and animals away from unit
10. Always cook on a firm, dry and level surface at least 12" from walls or any other obstruction
11. Do not use unit with a damaged cord or plug, in the event the appliance malfunctions, or has been damaged in any manner
12. Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury. All repairs should be done by authorized professionals only
13. Ensure that the power supply you are using is adequate for continual usage and the voltage is correct.
14. Unplug the unit when not in use

TO USE

1. First, remove unit from packaging.
2. Make sure the unit is placed on a firm flat surface before use.
3. Place liquid filled container(s) on the burner(s)
4. Plug the power cord into the appropriately rated outlet
5. Turn the switch to the plate(s) in use "On". Turn "Off" when not in use.

CLEANING - NOTE: To maintain cleanliness and increase service life, the plate warmer should be cleaned daily. Do not immerse the unit in water or any other liquid, if liquid enters the electrical compartment it may cause a short circuit or electrical shock)

1. Before cleaning or attempting to move warmer, unplug and let the unit cool completely.
2. Wipe the entire unit with a clean soft cloth until it is completely dry.
3. To avoid damage, do not use abrasive cleaners or scouring pads.
4. If soap or chemical cleaners are used, be sure they are completely rinsed away with clear water immediately after cleaning. Chemical residue could damage or corrode the surfaces of the unit.

WP-2



VER811

Warmer Plate - WP-2

Reference Number	Part Number	Description
1		Warming Plate
2A	WP-2A	Mica Heating Plate
3A		Mica Warmer Plate Holder
4		Fever Partition
5	WP-5	Power Cord
6		Bottom Cover
7		Body Frame
8	WP-8	Power Switch
10	WP-10	Rubber Foot

VER811

ACE Electrical Equipment One Year Warranty

ACE warrants its equipment against defects in materials and workmanship, subject to the following

conditions: This warranty applies to the original owner only, and is not assignable.

ACE Electrical Equipment is warranted for one year, effective from the date of purchase by the original owner. A copy of the original receipt or other proof of purchase is required to obtain warranty coverage.

Should any product fail to function in its intended manner under normal use within the limits defined in this warranty, at ACE's discretion, such product will be repaired, replaced with a refurbished unit, or replaced with a new unit by ACE, after defective unit has been inspected and defect has been confirmed. ACE does not assume any liability for extended delays in replacing any item beyond its control. This warranty does not apply to rubber and non-metallic synthetic parts where usage, wear, or lack of preventative maintenance may create abnormal replacement rates, and these parts are excluded from this limited warranty.

This warranty covers products shipped into the 48 contiguous United States, Hawaii, and metropolitan areas of Alaska and Canada. Warranty coverage on products used outside the 48 contiguous United States, Hawaii and metropolitan areas of Alaska and Canada may vary. Contact ACE for details at 1-800-223-7750

The following conditions are not covered by warranty:

- Equipment failure relating to improper installation, improper utility connection or supply and problems due to improper ventilation.
- Equipment that has not properly been maintained, damage for improper cleaning, and water damage to controls.
- Equipment that has not been used in an appropriate manner, or has been subject to misuse, neglect, abuse, accident, alteration, negligence, damage during transit, delivery or installation, fire, flood, riot, or act of God.
- Equipment that has the model number or serial number removed or altered.
- Equipment on which the security seal has been broken.

If the equipment has been changed, altered, modified, or repaired without express written permission from ACE, then the manufacturer shall not be liable for any damages to any person or to any property, which may result from the use of this equipment thereafter.

This equipment is intended for commercial use only. Warranty is void if equipment is used in other than a commercial application.

In the event your repair is not covered under the stated warranty provisions, parts are available by calling 1-800-223-7750. Equipment not covered by repair should be picked up from our warehouse facility within 10 business days from notification date. Any and all arrangements and expenses for the return of this merchandise is your responsibility.

"THE FOREGOING WARRANTY IS IN LIEU OF ANY AND ALL WARRANTIES EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILTY OR FITNESS FOR PARTICULAR PURPOSES AND CONSTITUES THE ENTIRE LIABILITY OF ACE. IN NO EVENT DOES THE LIMITED WARRANTY EXTEND BEYOND THE TERMS STATED HEREIN."

VER40111